

How to Change the Preset Postage Value in Your WJ Series

For the WJ60/65/90/95/110:

1. Press the Lock key to return to the HASLER screen.
2. Press the Supervisor button
3. Enter 9430
4. With the Green or Blue arrow key scroll down to #5 Setup
5. Press OK
6. With the blue arrow key scroll down to # 7 "Default Stamp Value"
7. Press OK
8. Enter 3 9 0
9. Press OK
10. Verify that the Preset Postage Value is 39 cents.
11. Press the Lock key to return to the Ready screen.

Log into User mode as normal to verify that the Default Value amount is 39 cents.

For the WJ20:

1. At the Ready screen press the MENU button.
2. Scroll with the Green or Blue arrow key until it says SETUP.
3. Press OK
4. Scroll with the blue arrow key until the screen says "PRESET POSTAGE"
5. Press OK
6. Enter 39 cents.
7. Press OK
8. Press the C key to return to the Ready screen.

Press the Lock key and log into the machine again to verify that the preset postage is 39 cents.